




TROUBLESHOOT

Your internet — CONNECTION —


1



Make sure your light is on. If the light is off check to make sure the side switch is on.




2



Check to see if your internet switch is on.



Select WS or WA.



This is what you want to see!